

	Original Recipe	
	minimum	maximum
powdered clay	25 kilos	25 kilos
water	12.5 litres	13.5 litres
N42 Sodium Silicate	100 grams (75 mL)	100 grams (75 mL)
Dispex N40	30 grams (21 mL)	40 grams (28 mL)

litres of slip produced	19 to 20
Aim litre weight/grams per litre	1725
biscuit	1060-1100°C/Orton Cone 04 to 03
glost	1000-1060°C/Orton Cone 06 to 04

❖ **Full contents of bag MUST be used in each mix** ❖
(Raw materials are NOT mixed)

Recommended Method

1. Add water to mixer.
2. Add minimum Sodium Silicate N42 diluted 50/50 with warm water.
3. Mix and put aside minimum Dispex N40 diluted 50/50 with warm water.
4. Agitate mixer as you add some of the clay: the slip will gradually thicken.
Add a small amount of Dispex N40 mixture to maintain fluidity.
Then add more clay.
Continue this process until all the clay is in the mixer and a smooth creamy consistency is obtained
the maximum amount of Dispex N40 should **not** have been needed to this stage.
5. Check the litre weight.
If litre weight is higher than the aim add water.
If litre weight is lower than the aim add clay.
For accurate litre weight measurement contact Walkers for a **litre weight bottle and calculation chart**.
6. Mix for 1 hour (more for multi bag mixes) then check if more Dispex N40 mixture is required for pouring fluidity.
7. Allow slip to mature for 24 hours.
8. Reblend.
9. Sieve through an 80 mesh screen before use.

For multi bag mixes proceed as above but leave addition of Dispex N40 until final adjustment.

Melbourne : 5 McLellan Street Bayswater 3153 03 8761 6322
Canberra : 289 Canberra Avenue Fyshwick 2609 02 6280 5700

TECHNICAL INFORMATION

Deflocculants

The amounts of Sodium Silicate or Dispex added to a casting slip are very critical and too much or too little may each result in the slip being too thick. If this happens, take a 1 litre sample of the slip and add one or two drops of Dispex.

If the slip becomes thinner after stirring then this shows that more is required to achieve good fluidity. If the slip becomes thicker then this shows that too much has been added already. Therefore more clay and water needs to be mixed into the slip in the same proportion as given in the casting recipe – no more Sodium Silicate or Dispex. The recipe can depend on the quality of the water supply, which may vary from one location to another and also may be affected by minor variations in the body's raw materials.

Maturing the slip

On standing overnight the slip may thicken up slightly. This will easily reblend when mixing is resumed, even by hand.

We recommend that a film of water, approximately 2mm deep, is placed on top of the slip after mixing. This will reduce water evaporation from the mix, especially in warmer weather.

Litre Weight Checks

The most important part of successfully mixing casting slips is getting the correct litre weight. For accurate and easy litre weight measurement contact **Walker Ceramics** for a **Litre Weight Bottle and Chart**.

Recycling Scrap

Great care is needed to avoid contamination, particularly from plaster moulds. Scrap should be kept in sealed containers in a plastic condition. Dry scrap will promote air inclusion in the slip. Recycle by adding a maximum of 20% of scrap. More than 20% can effect the quality of the slip. We recommend adding Barium Carbonate (BaCO₃) to the slip to remove sulphates, which may cause peeling faults. The amount of Barium Carbonate to add should be 0.1% (25gm per 25 kg bag) of the total dry weight of clay and scrap.

Faults and Remedies

Everybody who casts suffers from time to time from some form of casting trouble. Experience throughout the industry, combined with the extensive work done on casting slips in our laboratory has enabled us to connect the various faults with measurable properties of the slip. Of course, other factors besides slip properties can cause casting faults, but usually they can be easily noticed; for example, wet moulds causing slow casting, careless filling causing 'pinholes' or 'casting-spot', etc.

The table shown gives a brief description of each of the common troubles and the suggested remedies. This only gives the direction in which to move and it is up to the individual to determine how far they need to go.

Say you were suffering from flabbiness and you increased the dispex addition to correct this then found that you began to get brittle ware with casting spot, then you would know you had gone too far.

The following table will help you in recognizing and fixing common problems.

In all our slip recipes we recommend a maximum of Sodium Silicate - adjustment should only be made to Dispex.

Before making any adjustments make sure the litre weight is within the stated limits for the body .

Use our easy Litre Weight Bottle and chart

Fault	Description	Cause	Remedy Always check Litre weight first!
bad draining	slip failing to drain from narrow sections uneven surface on slip side of cast piece	fluidity too low or thixotropy too high (slip thickens too quickly)	increase water addition (if litre weight is too high) or increase dispex addition
brittleness	difficult to fettle or cut – giving jagged edges	thixotropy too low (slip too fluid)	decrease dispex addition
Casting spots scumming	discoloured patch appearing on the mould side of the article after firing, scum on surface of slip	thixotropy too low (slip too fluid)	decrease dispex addition or decrease water addition
cracking	small cracks on edges or where handles join the body of the article	thixotropy too low (slip too fluid)	decrease dispex addition
flabbiness	soft casts difficult to handle without distortion	thixotropy too high (slip thickens too quickly)	increase dispex addition
pin holing	small holes just beneath the surface on the mould side of the article	fluidity too low – air in slip	increase water addition (if litre weight is too high) or increase dispex addition
slow casting	casting time too long	fluidity too high or thixotropy too low (slip too fluid)	decrease water addition or decrease dispex addition
wreathing	small uneven ridges on the slip side of the article	thixotropy too low (slip too fluid)	decrease dispex addition

Thixotropy is the property of slips becoming thicker when they are at rest i.e. “thixotropy too high” means that the slip thickens up very quickly!